

F.W. Strickland
"Speed Slide"
Kiddie

STRICKLAND'S LANDING, INC.
WATERSLIDE OPERATING, MAINTENANCE AND INSPECTION
INSTRUCTION CHECKLIST

BLUE SLIDE OPERATING INSTRUCTIONS:

1. RUBBER AIR RAFTS ALLOWED ONLY.
2. NO DIVING FROM SLIDE.
3. SLIDE SINGLE (ONE AT A TIME) ONLY.
4. NO SLIDING ON KNEES OR FEET ALLOWED.
5. NO SLIDING UNTIL PERSON IN FRONT OF YOU HAS CLEARED FROM IN FRONT OF SLIDE.
6. NO JUMPING OR BOUNCING ON SLIDE.
7. CHILDREN WHO CAN NOT SWIM OR NEED ASSISTANCE BY ANOTHER SHOULD NOT USE THIS SLIDE.

cert # 00153

COPYRIGHT TOWN.COM

STRICKLAND'S LANDING INC.
WATERSLIDE OPERATING, MAINTENANCE AND INSPECTION
INSTRUCTION CHECKLIST

BLUE SLIDE MAINTENANCE AND INSPECTION INSTRUCTIONS:

1. DAILY BEFORE USE - CERTIFIED LIFEGUARD SHOULD INSPECT THE FOLLOWING:
 - A) INSPECT THE STEPS OF SLIDE FOR ANY LOOSE STEPS, BROKEN STEPS OR DAMAGE OF ANY KIND TO STEPS.
 - B) INSPECT BED OF SLIDE FOR ANY SCRAPES, FLAKING PAINT, JOINT PROBLEMS OR DAMAGE OF ANY KIND TO BED OF SLIDE.
 - C) INSPECT PIER UNDER AND AROUND SLIDE FOR BAD BOARDS.
 - D) INSPECT RAILING ON SLIDE FOR TIGHTNESS OR BREAK.
2. REPORT ANY DISCREPANCIES TO GENERAL MANAGER OR OWNER BEFORE OPENING SLIDE TO PUBLIC.
3. ANY REPAIR OR MAINTENANCE TO SLIDE SHOULD BE DONE BEFORE SLIDE IS OPEN TO PUBLIC.
4. IF DISCREPANCY OR NEED FOR REPAIR IS DISCOVERED DURING OPERATING HOURS, SLIDE IS TO BE CLOSED IMMEDIATELY UNTIL DISCREPANCY OR REPAIR IS COMPLETED.
5. ANY ACCIDENT OR COMPLAINT SHOULD BE REPORTED TO OWNER OR GENERAL MANAGER IMMEDIATELY.
6. SAFETY AND COMMON SENSE SHOULD ALWAYS GOVERN THE OPERATION AND REGULATION OF SLIDE.