


Mfg: CHILDRESS MFG.  
RIDE: CASTLE MANIA



CASTLE MANIA

220 VOLT

60 AMP

1 PHASE

Children must be 36in tall  
or be accompanied by an adult

SET UP

MAINTENANCE

CARNY TOWN . COM

## SETUP

1. Level trailer
  - a. across front
  - b. down sides
  - c. across back
2. Unpin scenery at back
3. Let down back platform and level
4. Raise upper platform & put support irons in
5. Raise bottom fence & pin , pin front scenery
6. Unpin top scenery and fence raise fence off floor & pin
7. Put top scenery iron in and pin to fence
8. Raise light tower & pin
9. Raise upper front scenery & pin
10. Unpin scenery and fence on upper front
11. Unpin scenery and platform on front bottom
12. Fold out bottom scenery
13. Raise light tower & pin
14. Hook snatch block on light tower & hook on platform

15. Raise platform half way pin bottom supports raise the rest of the way & pin bottom of supports to trailer
16. Raise hand rails & pin in place
17. Put upper scenery support in & pin to fence
18. Raise upper scenery & pin
19. Put signs up
20. Put quartz lights up put flags in
21. Hook winch on bottom of slide & unpin
22. Raise upper section of slide in place & pin on bottom
23. Put second section of slide in place & pin raise bottom section of slide & block solid
24. Put bottom section of slide in place & pin
25. Put fence & hand rails in place
26. Make sure all rkey's are in place
27. Pull out ball crawl bottom supports & ball crawl
28. Remove front jacks from under trailer and set in front corners

MAINTENANCE

DAILEY

CHECK PINS

CHECK R KEYS

CHECK SLIDE

CARNYTOWN.COM